

TECHNICAL DATA SHEET

Removers, Cleaners Product Code **1891/1893/1897/1899**

Swing Paints Limited 2100 St Patrick Street Montreal QC CANADA H3K 1B2 514-932-2197

Professional Stripper

Paint & Varnish Remover



Packaging

SIZE	CASE PACK	CASE WEIGHT
3.78 litre (1 US gallon)	2	10 kg (22 lb)
18.9 litre (5 US gallon)	1	30 kg (65 lb)
205 litre (55 US gallon)	1	300 kg (650lb)

Specifications

SOLVENT: COLOUR: OPACITY: ODOUR: VOC RANGE: FLASH POINT: FLASH POINT:

APPLICATION TEMPERATURE: APPLICATION HUMIDITY: OPEN TIME

SURFACE COVERAGE: SHELF LIFE:

Clear to White
Transparent to Milky
Characteristic
260-290g/L (2.2-2.4 lb/gal)
N/A
Non-flammable
5-30°C (40-85°F)
N/A
15-60 minutes
10m²/L (400ft²/US gal).

10 years (unopened)

Methylene Chloride

Product Description

Swing Professional Strippers are clean, non-grain raising strippers designed for removing paint; varnish; polyurethane; lacquer; moisture cure, etc. They do not contain any caustic or water, and are nonflammable. Swing Professional Strippers come in four formulations: Swing Professional Flo Stripper (1893), a very low viscosity remover for spraying and overflow tanks, as well as a stripper wash or as a diluant for stripper tanks that have become too thick: Swing Professional Liquid Stripper (1897), a low viscosity remover for spraying, standing baths and dip tanks; Swing Professional Gel Stripper (1899), a high viscosity remover that is ideal as a first stage remover for difficult finishes and for standing baths; Swing Professional Super Stripper (1891), an extra strength remover for catalyzed, moisture cure and epoxy finishes.

Recommended Uses

Swing Professional Strippers can be used on wood, metal, masonry, and brick. Always test the stripper on a small, inconspicuous area for application on plastic surfaces. **Swing Professional Strippers** are recommended for interior and exterior use.

Directions

Surface Preparation - Remove handles and knobs. Clean surface to remove wax and dirt with TSP and warm water, or other applicable cleaner.

Application – Brush on a liberal amount of Swing Professional Stripper. Wait at least 2 minutes for the finish to bubble or dissolve. Remove the dissolved finish using a brush or Circa 1850 Maple Scraper to prevent gouging on wooden surfaces. If finish is exceptionally thick, and some residue remains, repeat the procedure a second time. When all the finish has been removed, wash down the surface with mineral spirits or water using medium (00) synthetic pad. No afterwash is required for Swing Professional Flo Stripper.

Dry Time - Allow the surface to dry thoroughly (1 hr under normal conditions) prior to applying a topcoat. High humidity or low temperatures may slow drying.

Caution

Store container in a cool, dry place. Always wear Circa 1850 Stripping Gloves (impermeable rubber gloves) and protective eyewear. Work in a well ventilated area. In case of contact with eyes or skin, flush thoroughly with water. If swallowed call physician immediately.